

A46
Fuse holder, rear

X11010

30<50
2.5
RT/WS

1

X10547

15WUP
0.35
RT/GN

13

X10552

PT_CAN_L
0.5
RT


16

X10551

PT_CAN_H
0.5
BL/RT

9

X13663



A13663
Fuel pump control
(EKPS)

X13663

31
2.5
BR

2

2

EKP--
2.5
BR

X18203


EKP+
2.5
RT/WS

4

1

X638

4



I01070
Fuel tank

X13792