

A7000

AGS transmission
control unit


31

X70004

U_GETRPO
0.75
GN

5

X8532



S8532

Gear position switch

0) Low (Off)

1) High (On)

1

3

4

2

X8532

L1
0.5
SW

L3
0.5
VI

L4
0.5
GE

L2
0.5
OR


34

14

4

24

X70004



A7000

AGS transmission
control unit