



F50

F32

F50

A2
Instrument cluster

A2
Instrument cluster

F50

I01043
Mobile phone

A117
Eject box

I01040
Interface

H38
Transceiver/charging electronics

B400
Microphone

I01127
Telephone aerial, right

I01128
Telephone aerial, left

I01039
Compensator

I01040
Interface

30<50

R<32

30<50

30<50

30<50

R<32

R<32

30<50

30<50

31

K-BUS

SWA+

DNLINK

UPLINK

ON/OFF

DSCEN

TXAUD

LGND

MIC+

MIC--

B400
Microphone

30<50

I01127
Telephone aerial, right

I01128
Telephone aerial, left

I01039
Compensator

TELON

I01040
Interface

31

31

MUTE

LS+

LS--

H65
Hands-free unit

N9
Radio

31

31

31

31

31

31

31

31

31

31

31

31

31

31

31

31

30

30

30

30

30

30

30

30

30

30

30

30

30

30

MUTEC

MUTEC

EXTB+

VEXTB+

BATT.F

CH_GND