




A568

Gear selector switch (GWS)

3) START-STOP button

A528

Basic central platform (BCP)