
without automatic gearbox
Z44
Front right power distribution box
30B
F71
5A
48
30B<71
0.35
RT/BR
B155a
Gear sensor
2
3
4
B446*1B
U_5V_2
0.35
BL
SENT_GS
0.35
GE
M_GS
0.35
SW
16
19
22
A463*5B
15(5V)
31
A460
Digital diesel electronics
S63
START-STOP button
4
5
9
10
2
6
1
S63*1B
SSP1
0.35
GN
31_SSP1
0.35
BL/GN
SSP2
0.35
WS/BL
31_SSP2
0.35
GE/GN
LED_SSP
0.35
WS
MSA_LED
0.35
OR
MSA
0.35
SW/WS
45
46
49
50
44
47
43
A258*7B
A258
Body Domain Controller
50
23
22
A258*3B
1
A258*2B
KUPPL
0.35
BL
S_BLS
0.35
BL/RT
50L
2.5
SW
2
S25*1B
S25
Brake light switch
3
S25*1B
9
X13*1B
50L
2.5
SW/GE
B57 engine
WS
B58 engine
RT/WS
N63/S63 engine
3
S50*1B
S50
Clutch module
2
S_KUP
0.35
BL/BR
28
A46*1B
1
S50*1B
31
0.35
BR/SW
Z10*4B
right-hand drive
Z10*3B
left-hand drive
31
0.35
BR/SW
up to 2017_06
from 2017_07
X311*1V
Z10*3B
1
M92*1B
M92*2B
M92
Starter
B+
85.0
RT
Z4*1B
with dual storage system
Z4*4B
without dual storage system
Z4
Front power distribution box
Z4*3B
B+
59.0
SW
RT
Z3*3B
with dual storage system
Z3*2B
without dual storage system
Z3
Fuse box
Z3*1B
B+
50.0
RT
G1*1B
G1
Battery
31
X6402