
A12e
Crash safety module
X2
Steering column switch cluster
X10001
X10002
X10003
X10004
X10005
X10006
X10071
X10072
E6
Inflator assembly, driver's airbag
X1983
X257
X258
SAVF5+ 0.5 AT
SAVF5– 0.5 BLNT
Z19c
Inflator assembly, side airbag, driver
X1981
X274
X275
SAVF+ 0.5 AT
SAVF– 0.5 BLNT
Z20c
Inflator assembly, side airbag, rear driver's side
X1986
X14339
X14340
X10770
X10771
ESF+ 0.5 GE/RT
ESF– 0.5 GE/BR
Z17a
Inflator assembly, driver's side head airbag
E26
Generator for and lifting pretension-er, driver's seat
EUR
X10216
X10217
X10218
X10219
GSF+ 0.5 GE/RT
GSF– 0.5 GE/BR
E13
Belt tensioner, driver
X13038
X13039
X13040
X13041
AKSF+ 0.5 GR/BR
AKSF– 0.5 GR/SW
Z18a
Generator for air-bag head restraint, driver's seat
X10800
X10801
X10802
X10803
ESF3+ 0.5 GE
ESF3– 0.5 BL/GE
Z19a
Generator, seat belt pretensioner, rear passenger's side
E7
Inflator assembly, passenger's airbag
X1984
X256
SAVSF5+ 0.5 AT
SAVSF5– 0.5 BLNT
Z19b
Inflator airbag inflator assembly, passenger
X1782
X1783
X1784
X1785
X273
SAVF+ 0.5 GN
SAVF– 0.5 BL/GN
Z20b
Inflator assembly, side airbag, rear passenger's side
X1985
X1986
X1987
X1988
KSSF+ 0.5 GN
KSSF– 0.5 BL/GN
Z19d
Inflator assembly, passenger's side head airbag
X10217
X10218
X10219
X10220
GSSF+ 0.5 GE/RT
GSSF– 0.5 GE/BR
E13
Belt tensioner, passenger
X13039
X13040
X13041
X13042
X279
KSSF+ 0.5 GR/BR
KSSF– 0.5 GR/SW
E6
Generator for air-bag head restraint, passenger's seat
X10218
X10219
X10220
X10221
ESF3+ 0.5 GE
ESF3– 0.5 BL/GE
Z19e
Generator, seat belt pretensioner, rear driver's side
X10220
X10221
X10222
X10223
X10224
X10225
X10226
X10227
SBK+ 0.5 BR/RT
SBK– 0.5 BR
Z19a
Generator, safety battery terminal