
Z44
Front right power distribution box
F67
F68
F60
30B<67
0.35
RT/GN
30B<68
0.35
RT/GN
30B<60
0.35
RT/BL
30B<60
0.35
RT/BL
S19*1B
S19
Seat switch cluster on driver's door
S23*1B
S23
Seat switch cluster on passenger's door
S27*1B
S27
Seat switch cluster, rear driver's side door
S28*1B
S28
Seat switch cluster, rear passenger's side door
31
0.35
BR
FAT_LIN
0.35
WS/BL
BFT_LIN
0.35
WS/BL
FAT_LIN
0.35
WS/GN
BFT_LIN
0.35
WS/GN
X117*1V
X140*1V
X119*1V
X550*1V
X120*1V
X120*1V
X1323*1V
X315*1V
X315*1V
X1324*1V
A258
Body Domain Controller
A258*8B
K_CAN2_H
0.35
GE/BR
K_CAN2_L
0.35
GE/RT
R2*1B
R2a
CAN terminator 2
Z10*46B
BR
BR/SW
0.5
S11
Seat adjustment switch cluster, rear driver's side
S11*1B
AD4
0.35
GE/BL
GND
0.35
BL/GN
X200*1B
AD4
0.35
WS/GE
GND
0.35
BR/OR
X1320*1B
AD4
0.35
WS/GE
GND
0.35
BR/OR
A348*1B
A348
Rear right seat inflator module
Z2a
Power distribution box, rear
F263
7.5A
Z2*5B
30B<263
0.75
RT/BL
31
0.75
BR
X254*1V
W9110.2
P_PWM_HR
0.35
RT
GND
0.35
WS
M4*1B
M4b
Seat pneumatics module pump, rear right
LO_CAN_H
0.35
BL/RT
LO_CAN_L
0.35
BL/BR
X1320*1B
S13
Seat adjustment switch cluster, rear passenger's side
S13*1B
X1319*1B
A351*1B
A351
Rear left seat inflator module
X249*1V
P_PWM_HL
0.35
RT
M82*1B
M82b
Seat pneumatics module pump, rear left
30B<64
0.35
RT
X14*1B
X641*1V
S153
Seat adjustment switch block, driver's side
S153*1B
A350*1B
A350
Front right seat inflator module
P_PWM_VR
0.35
RT
M216*1B
M216
Seat pneumatics module pump, front right
without Captain's Chair
F65
30B<65
0.35
RT
X12*1B
X642*1V
S154
Seat adjustment switch block, front passenger side
S154*1B
A349*1B
A349
Front left seat inflator module
P_PWM_VL
0.35
RT
M215*1B
M215
Seat pneumatics module pump, front left