
A46
Fuse holder, front
F20
F24
F60
F86
F13
F84
7.5A
F82
30A
A12
Airbag diagnostic module
N8
Antenna amplifier
A22
Electrochromic interior rear view mirror
S309
Switch, bottom tailgate
K112
Relay, bottom tailgate motor
K70
Rear lid motor relay
M407
Boot lid servo motor
A23
Driver's door module
A24
Passenger's door module
A1
General module
M12
Central locking drive, driver's door
M13
Central locking drive, front passenger's door
M15
Central locking drive, rear left door
M14
Central locking drive, rear right door
M16
ZV drive tank flap
M123
Motor, bottom tailgate
S117
Rear lid unlocking switch
A169
Switching centre
S18
Hazard warning flasher switch
30×20
P-BUS
30×24
30×86
30×13
FBZV
IRFB
With radio remote control
With infrared remote control
CA
30×60
30×84
TOEHKU
30×82
MERHK
MOT1
MOT2
SCA_A
SKS1
SKS2
ZRS
31E
SCA_Z
31L
VRFT
ERFT
TKFT
MZS
MER
MVR
TKBFT
TKFH
TKBH
MERHKU
TOEHK
TZV
TOEHKI