
J128
Basic central platform (BCP)
A83
Steering column switch cluster
E121
Interior light, front
E181
Interior light, rear
J245
Front left power distribution box
J244
Front right power distribution box
E113
Vanity mirror light, front left
E114
Vanity mirror light, front right
E384
Vanity mirror light, front passenger backrest trim lighting
E263
Driver backrest trim lighting
Switch, vanity mirror, front left
Switch, vanity mirror, front right
W Sport seat European version
T070
Luggage compartment
E124
Luggage compartment light
Tailgate lock
E362
Footwell light, front passenger
T1 - Light source 1
E363
Footwell light, driver
T1 - Light source 2
J533
Data bus diagnostic interface
J519
Vehicle electrical system control unit
J533
Data bus diagnostic interface
J513
Door control unit, driver's door (TSG/FS)
E182
Driver's door entry lighting
E371
Door pocket lighting, driver's
T1 - Light source 4
E369
Inside door handle light, driver's
T1 - Light source 3
E370
Inside door handle light, rear of driver's side
T1 - Light source 5
E377
Door pocket lighting for the door on passenger's side rear
T1 - Light source 6
E189
Centre stack lighting
T1 - Light source 1
J514
Door control unit, passenger door (TSG/BF)
E183
Front passenger door entry lighting
E372
Door pocket lighting, front passenger door
T1 - Light source 5
E376
Inside door handle light, front passenger door
T1 - Light source 2
J242
Front right power distribution box
E378
Door pocket lighting for the door on passenger's side rear
T1 - Light source 5
E394
Inside door handle light, rear passenger door
T1 - Light source 4