
B789 Pedestrian protection sensor, outer left
B790 Pedestrian protection sensor, outer right
B791 Pedestrian protection sensor, centre
B797 Front left pressure sensor for pedestrian protection
B798 Front right pressure sensor for pedestrian protection
USA/China
B61 Airbag front sensor, left
B45 Airbag front sensor, right
B80 Airbag sensor, door, front left
B28 Airbag sensor, door, front right
Right-hand drive
Left-hand drive
B785 Airbag sensor, B-pillar, left
B786 Airbag sensor, B-pillar, right
S7 Driver's seat belt buckle contact
without electric seat adjustment
S81 Seat-position sensor, driver
S48 Front passenger's seat belt buckle contact
S61 Seat-position sensor, front passenger
S263 Seat belt buckle contact, rear left
A661 Seat occupancy detection, rear left
S264 Seat belt buckle contact, rear centre
A563 Seat occupancy detection, rear centre
S265 Seat belt buckle contact, rear right
A662 Seat occupancy detection, rear right
S349 Backrest lock switch on driver's side rear
S350 Backrest lock switch on passenger's side rear
A17*2B Crash Safety Module (ACSM)