
A108
Basic central platform (BCP)
A2
Air conditioning control panel
X9A0
X9A0
Diesel engine
N2
Blower output stage
M7
Ventilator flap motor
A16
Fresh air/recirculated air flap motor
M11
Footwell flap motor
M9
Mixed air flap motor, right
M10
Mixed air flap motor, left
X10/2*1V
X10/2*1V
X10/2*1V